www.rottweilersystems.com

SAMSUNG OFFICESERV SYSTEM SPEED DIAL PROGRAMMING GUIDE

To Change Or Add System Speed Dials Through the Samsung Handset:

- From any handset press the **Transfer key** and dial [2][0][0], the display will show **ENABLE CUS. PROG. & PASSCODE**:
- Enter the passcode which is [1][2][3][4] as a factory default
- Press [1] to ENABLE CUS. PROG, then press the Speaker Key
- Enter the system speed dial program by dialing [7][0][5]
- Dial the speed dial number required (e.g. [5][0][5]) OR press volume **UP** or **DOWN** to make your selection
- Once you have the right speed dial number press the right soft key (*under the display*) to move the cursor under the numbers
- Enter the line access code (e.g. 9 the system automatically inserts a dash) followed by the phone number (up to 18 digits long).
- Press the right soft key to return to the speed dial number to change or add more numbers
- ONCE YOU HAVE FINISHED ENTERING THE SPEED DIAL NUMBERS PRESS THE TRANSFER KEY TO SAVE & EXIT PROGRAMMING